

# W Connectors Quick Start Guide



Step 1: Line up the two white dots on the male and female side of the connector.



Step 2: Push the two ends of the connector together until they are fully connected.



Step 3: Once fully connected take the male side in your right hand turn the blue ring clockwise to fully lock and seal the connector.



**Final connection**



**Dynamax**

(281) 564-5100 [www.dynamax.com](http://www.dynamax.com)